

Mammoth® 100% polyester insulation is safe and easy to install. Mammoth Panel Absorber is designed to be used as an interior surface lining in commercial and residential spaces to help reduce noise reverberation.

Before you get started

- Mammoth is safe to install - it will not irritate your skin when you touch it.
- Keep the product dry at all times. Do not use Mammoth Acoustic Panel Absorber in situations where the product will come into contact with water or moisture. Allow a minimum gap of 25mm from any building surface that is damp or may become damp during the intended use of the building.
- Avoid compression of the product, as it will adversely affect performance. Nominal thickness of the product should be kept at all times.
- Use sufficient product so that a snug fit is achieved. Cut to required lengths using a Tajima knife or other heavy duty blade.
- For further safety information on installing insulation refer to NZS4246 Appendix B and the HSE Act.

Recommended tools

- Insulation hangers (52mm) and hanger caps
- Acrylic spray paint to paint insulation hanger caps
- Contact adhesive (EVA type) and construction adhesive
- Tajima knife (model LC660) or a similar heavy duty blade
- Steel ruler and tape measure and/or digital laser meter

Things to look out for

Electrical Wires

- Mark the position of services; eg electrical wires and telephone lines as you need to cut the insulation accordingly.
- When working near electrical cables and equipment, care should be taken to avoid damaging any electrical insulation.
- Where possible fit Mammoth Panel Absorber behind electrical wires or pipes
- Refer to a registered electrician or qualified electrical engineer and/or AS/NZ 3000 for further guidance.

How to install Mammoth Panel Absorber

Mammoth Acoustic Panel Absorbers can be applied to walls and ceilings in a variety of ways. These include friction-fitted into a frame, glued and fixed using Insulation hangers. These instructions include adhesive fixing and mechanical fixing (with insulation hangers).

Adhesive fixing requirements

Ensure the surface is clean and dry.


- Measure the entire surface you are covering & ensure you have enough Panel Absorbers.
- Ensure surface meets adhesive requirements, all gaps and joins to be covered, substrate to be prepared to a minimum level 3 finish.
- Measure Mammoth Panel Absorber and cut sheet to size if required.
- Two (2) adhesives must be used. Full coverage of contact adhesive on substrate and panel for primary adhesion combined with a secondary construction adhesive at minimum 150mm strips across the panel.
- Recommended 25mm negative detail, product can be butt joined but is not recommended for aesthetic reasons.
- For more details, refer to adhesive manufacturers recommendations.

Disclaimer: Mammoth Panel Absorber is designed for acoustic applications. It is not recommended for visual applications as the surface may show creases, wrinkles or slight colour variations due to the manufacturing process.

Mechanical fixing requirements

Ensure the surface is clean and dry.

- Measure the entire surface you are covering & ensure you have sufficient Panel Absorbers to cover.
- Ensure you have sufficient Insulation hangers to complete a 600mm x 600mm spacing across the surface.
- Ensure surface meets adhesive requirements.
- Using a pen or permanent marker, mark up where the Insulation hangers are to be positioned on the clean surface.
- Fix the Insulation hangers onto the surface with screws or nails. If using glue, apply a sufficient amount of construction adhesive glue onto the base and glue them to the surface. NB: ensure you maintain the 600mm centre intervals.



- For additional strength, apply contact adhesive and/or construction adhesive between the Insulation hangers. Be mindful of porous surfaces with contact adhesive.
- Measure Panel Absorber and cut sheet to size.
- Line up the Mammoth Acoustic Panel Absorber to an outer edge first and then push the panel onto the insulation hanger.
- For safety, note the insulation hanger's position when applying onto the surface.
- Fix insulation hanger caps onto the ends of the facing pins, so that it fits up against the Panel Absorber without compressing. If necessary, a suitable washer can be applied before the cap.



- If necessary, paint caps to match the colour of the Mammoth Acoustic Panel Absorber.

Current as at August 2022.